




# TV SCHEMATIC DIAGRAM



**Notice:**

- (1) 38C: 28C54-R/7/8; 28C1818-O/7/GR;
- (2) 28A: 28A698-R/P; 28A1015-O/7/GR;
- (3) D: 181555; 18A148; 182473; 182076; D8443;
- (4) 0.01: CV1-068-294-63V-0.01uF-S;
- (5) 2K470: CV1-068-284-63V-470uF-X
- (6) XXXXX: CV1-63V-222uF-S

SS2

Note: Without notification for any specification change!